



FIG. 1





00200T-65592960

FIG. 2



00200T 6559 100200

**FIG. 3****FIG. 7**

00200T" 65594960

FIG. 4




FIG. 5

	OUTPUT PORT NUMBER															
	5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0
001 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
002 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
003 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
004 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
005 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
006 <sub>H</sub>																
00F <sub>H</sub>	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
010 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1
011 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1
012 <sub>H</sub>	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	1
⋮																
⋮																
⋮																
⋮																
FFF <sub>H</sub>																

FOR UNICAST

FOR MULTICAST

002001" 65597960

KIND OF INDEX INFORMATION

00200T"6559/960

FIG. 6

